
Technical Bulletin

Using line cords correctly

Line cords can be damaged if they are not fully seated in the inlet connector of the projector.

If the projector needs to be powered down, or power-cycled, the breaker must be used to power down the projector. Do **not** remove the line cord from the appliance inlet when the projector is powered.



Affected products

Inspect the following products to ensure the line cord is properly installed.

- All Christie cinema projector models.

Technical support

Technical support for Christie products is available at:

- North and South America: +1-800-221-8025 or Support.Americas@christiedigital.com
- Europe, Middle East, and Africa: +44 (0) 1189 778111 or Support.EMEA@christiedigital.com
- Asia Pacific: +65 6877-8737 or Support.APAC@christiedigital.com
- Christie Managed Services: +1-800-550-3061 or NOC@christiedigital.com