

---

# Software Release Notes

---

## Christie Spyder X20 v4.0.7

### Affected products

- Christie X20 v4.0.7

### Purpose of v4.0.7 release

- Added the Pesa P1N redundancy router protocol.
- Fixed an issue with Command keys missing after restoring the config file.
- Added USB redundancy for expanded systems.
- Fixed an issue with Dual link resources.
- Fixed an issue where Command keys would lose the color value when applying a Repair Data List.
- Added the OCC (Output Config Connection) external command.

### Upgrade Instructions

Start Vista Advanced v4.0.7.

Go to the Server\Connection Manager.

In the Connection Manager panel, choose Select Server and identify the IP address of the Spyder you want to update. If the Spyder unit is currently running another version (other than v4.0.7), the Connect tab will change to Update. Selecting Update will begin the process of updating to v4.0.7. The update will take approximately 10-15 minutes.

The front LCD panel will prompt you to Power Cycle Now when nearing completion. To power cycle, toggle the front panel button and the Spyder unit will shut down. Remove the power cords from the power supplies, wait 10-15 seconds, and reinsert the power cords.

Restart by toggling front panel button. The front panel LCD will display v4.0.7 when the Spyder unit has completed the update.

### Technical Support

For support for this product, visit:

<http://www.christiedigital.com/en-us/product-support/support-offices/Pages/default.aspx>