

# Accessing the projector user interface

This document provides information on how to access the user interface (Remote UI and VNC) when the projector does not have a touch panel.

## Affected products

The following products are affected.

- Projectors with CineLife+ running v1.3.0 or later

## Determining the projector IP address

Before accessing the projector user interface, you must determine the IP address of the projector.

1. To display the IP address, connect the projector to the theater network using an Ethernet cable, then press and hold the marriage button on the projector for 5 to 25 seconds.  
The projector powers on and displays a test pattern on the screen. The test pattern gives the projector's IP address and any currently active alarms.  
To reset the projector to the default IP address, press and hold the marriage button for 30 seconds.
2. In a browser on a computer connected to the same network as the projector, navigate to the IP address of the projector.  
The default IP address of the projector is 192.168.206.110 and the subnet is 255.255.255.0.

## Using the Remote UI

Use the remote UI to access projector functionality.

1. Log into the Remote UI.
2. From the Remote UI default page, access the main projector user interface by clicking the **Projector Control** tab.
3. To upload and download files from the Projector, use the File Menu.  
Examples of items that can be uploaded include:
  - Projector Upgrade packages
  - Backup packages to restore from
  - Rental files to license the projector for Rental mode
  - Test Patterns (PNG files only)

- Gamma files

Examples of items that can be downloaded include:

- Projector Backup files
- Projector Certificates (required for content decryption)
- Interrogator files (for support and troubleshooting)

4. If the projector has a GDC IMB SR-1000 installed and configured, you can access the GDC IMB Web UI by using the **Media Block** tab.

## Using VNC

Use VNC to control the projector.

1. Run the VNC Software on your computer.
2. Enter the projector IP address.
3. If required, enter the port number 5800.
4. Enter the VNC password.

If you do not know the VNC password, contact Christie Technical Support.

## Technical support

Technical support for Christie Cinema products is available at:

- [Support.cinema@christiedigital.com](mailto:Support.cinema@christiedigital.com)
- +1-877-334-4267
- Christie Professional Services: +1-800-550-3061 or [NOC@christiedigital.com](mailto:NOC@christiedigital.com)